


Upgrading the registration on a Franklin Fueling System's tank monitor*

June 11, 2015 • TB0615-01

Upgrading the registration of the tank monitor is needed when adding new software features to the tank monitor.


For example, if LLD or SCALD is added, a code will be sent. Copy and paste this code into the tank monitor, save the changes, and the program will be activated (refer to step 5).

1. When you go the main screen on the web interface of the tank monitor it should look like this:




TANKS													
Image	Manifold ID	Tank ID	Name	Product	Alarms	Level	Gross Volume	Net Volume	Ullage	Water Level	Temperature	Max Capacity	Capacity %
		1	Unleaded Tank	Unleaded	⊕	92.94	16,786.69	16,688.48	2,995.31	0.00	68.31	19,782.00	84.86
		2	Premium Tank	Premium	⊕	96.78	6,915.55	6,877.73	985.45	0.00	68.78	7,901.00	87.53
		3	Diesel	Diesel	⊕	96.45	9,210.10	9,171.34	1,209.90	0.00	69.25	10,420.00	88.39

2. Highlight only the “tank_status.html” on the address bar.




3. Type in “register” and press enter:




* This includes T5 Series, the TS-550/5000evo and Colibri™ consoles

4. The registration page looks like the one below. In the upper right hand corner, click on “Register” It will be right under the alarm green, yellow, or red display light depending on the alarm conditions of your tank monitor



5. Finally copy and paste the code supplied into the white text box, and then click “Yes” to save your registration information.



Note: When copying the code, it is important to select the entire code and nothing more (including blank spaces).

If you have any questions about this procedure, contact Franklin Fueling Systems Technical Support (800-984-6266)