

## Ordering Consoles from the Factory



**FORMAT:** The Tank Sentinel® part number is divided into three sections: Model, Hardware Options/Software Options.

**EXAMPLE:** T2P/8S (TS2001 with a printer option/software SCALD option that supports eight tanks).

### Model

The following table shows the values that the Model section can assume.

MODEL	VOLTAGE	MODEL CODE
TS-1001	120 VAC	T1
TS-1001	220 VAC	V1
TS-2001	120 VAC	T2
TS-2001	220 VAC	V2
TS-504	120 VAC	T504
TS-504	220 VAC	V504
TS-508	120 VAC	T508
TS-508	220 VAC	V508
TS-750	120 VAC	T750
TS-750	220 VAC	V750

### Hardware

The following table shows the values that the hardware section can assume. Note that the order of the specific option in the final part number is fixed. The order of the options in the table reflects this (i.e. P will always be before M).

HARDWARE	OPTION CODE	TS-1001	TS-2001	TS-504	TS-508	TS-750
Printer	P	Std.	Std.	Yes	Yes	Std.
Internal Modem	M	Yes	Yes	Yes	Yes	Yes
Internal Expansion Module	1 or 2	No	Yes	No	No	No

**Notice:** The order of specific option in the table determines position in the final part number. ALL options except the Internal Expansion Module are determined by a setting programmed into the ID chip. Internal Expansion Modules is determined at power up via presence of hardware module(s).

### Software

The following table shows the values that the software section can assume. Note that the order of the specific option in the final part number is fixed. The order of the options in the table reflects this (i.e. 8 will always be before S, which should always be before D).

SOFTWARE	OPTION CODE	TS-1001	TS-2001	TS-504	TS-508	TS-750
Number of tanks	0, 2, 4, 8	0, 2, 4	8	4	8	1, 2, 3, 4
SCALD or Generator	S, G	Yes	S	No	No	S
Data Fax/Data Modem	D, F	Yes	Yes	Yes	Yes	Yes
Continental version	C	Yes	Yes	Yes	Yes	Yes
Line Leak Detection	L	Yes	Yes	Yes	Yes	No
Reconciliation	R	Yes	Yes	Yes	Yes	No

**Note:**

- The order in the table determines the part number.
- SCALD and Generator options are mutually exclusive. The SCALD option is not needed for the generator model.
- Data and Fax/Data Modem options are mutually exclusive.